

Betriebsanleitung
 Operating Instructions
 Instructions de service
 Istruzioni d'uso
 Handleiding
 Instrucciones para el manejo
 Manual de instruções
 Naudojimosi instrukcija
 Kasutusjuhend
 Lietošanas instrukcija
 Driftsinstruks
 Driftsinstruktioner
 Käyttöohje
 Driftsvejledning
 Instrukcja obsługi

Kezelési útmutató
 Návod k obsluze
 Navodilo za uporabo
 Návod na obsluhu
 Upute za rad
 Manual de operatii
 Treoracha Oibriúcháin
 Οδηγίες χρήσης
 El Kitabi
 Инструкции за експлоатация
 Инструкция по эксплуатации
 取扱説明書
 사용설명서
 使用说明书

VXLF 2.200
VXLF 2.250

2006/42/EG









DIN EN ISO 14001:2005










DIN EN ISO 9001
001929 QM

				mbar
				m ³ /h
			<p> $L_{pA} = 75-80$ dB(A) - 50Hz $L_{pA} = 77-82$ dB(A) - 60Hz $K_{pA} = 3$ dB(A) </p>	<p> DIN EN ISO 3744 </p>


	<p>222-280 kg 490-617 lbs</p>	<p> $A > 400$mm $A > 16$" </p>	<p> $> 5^{\circ}\text{C}/41^{\circ}\text{F}$ $< 45^{\circ}\text{C}/113^{\circ}\text{F}$ </p>	<p>max. 90%</p>	<p>max. 800m</p>
<p>1</p>	<p>2</p>				








E.



F.




G.

VXL F 2.200 **SK**
VXL F 2.250 **SK**


F1: D: 218 mm
H: 122 mm
No.: **9095120000**
F1: (polyester)
VXL F 2.xxx/6
No.: **9095960000**

EN149 - FFP3
42 CFR 84 - N100


F2: D: 64 mm
H: 120 mm
2x No.: **9095100000**







I.



J.



<p> $A_{MAX} = 64\text{mm}$ $A_{MIN} = 41\text{mm}$ $A_{\text{fan}} < 41\text{mm}$ </p>	
<p>VXLF 2.200/2.250 → No. 90132500005 (SET) L.</p>	



BECKER
 Bedienungsanleitung Diferențialul
 Operating instructions Diferențialul
 Instructions de service Kalkulator
 Инструкция по эксплуатации Diferențialul
 Handledning Instrucțiunile
 Instrucciones para el montaje Pasos de montaje
 Manual de instalação Notas de instalação

www.becker-international.com



Gebr. Becker GmbH
 Hölker Feld 29-31
 D-42279 Wuppertal
info@becker-international.com

SERVICE
www.becker-international.com
 Sales and service network